
Sensors ECU A
Camshaft Sensor
Crankshaft Sensor
Intake Air Temperature Sensor
Boost Pressure Sensor
Power Lever Sensor
Shared Sensors
Gearbox Temperature Sensor
Oil Temperature Sensor
Fuel Pressure Sensor
Rail Pressure Sensor
Oil Pressure Sensor
Coolant Temperature Sensor
Fuel Temperature Sensor
Sensors ECU B
Camshaft Sensor
Crankshaft Sensor
Intake Air Temperature Sensor
Boost Pressure Sensor
Power Lever Sensor
EECU
ECU A
ECU B
Shared Sensor Signal Conditioning
Relay Matrix
Actuators
Injectors (4)
Boost Pressure Acutator
Rail Pressure Control Valve
Governor Actuator
Fuel Metering Unit
Fuel Pump A
Fuel Pump B
Caution Lamp A
Caution Lamp B