


## ATA 32 – LANDING GEAR

### Engine Power Lever Switches

- With the MLG retracted, if one or both engine power levers are moved towards the IDLE position (below 25%), the engine power lever micro switch(s) close, energizing the gear warning relay.
- An audible warning horn will operate and

### GEAR CHECK is displayed on the PFD.

- When both power levers are moved towards take off (above 25%) or the landing gear handle is elected down, the warning system deactivates.



Engine Power Lever Switch Installation